NoiseMeters

Acoustic Calibrator - Class 1



Features

- IEC 60942:2003 Class 1
- ANSI S1.40:2006
- Sound pressure level 94 dB
- Frequency 1 kHz
- Fits ¹/₂" microphones
- Adapter available for 1/4" microphones

Applications

- Calibration check of Class 1 sound level meter
- Field calibration checks
- Calibration of environmental noise monitors
- Required by many noise regulations

Overview

The CR515 Acoustic Calibrator meets ANSI S1.40:2006 and IEC 60942:2003 to Class 1, the more accurate grade. It is most suited to the Class 1 sound level meters and environmental noise monitors that NoiseMeters offers.

This calibrator is included in most of the Class 1 Noise Measurement Kits and Outdoor Noise Kits, along with the sound level meter, carrying case and software where applicable. Please refer to the sound level meter web pages for more information.

Using It

As soon as the calibrator is switched on it emits a 1 kHz tone at 94 dB. The calibrator should be pushed carefully (firmly, but slowly) on to the microphone capsule.

The meter should now be adjusted accordingly. There will often be a free-field adjustment to make for the microphone in use. So, for example, you may actually be adjusting to 93.8 dB on the meter. For meters provided by NoiseMeters this is either dealt with automatically by the meter, or is covered in the meter's User Manual.

NoiseMeters

Acoustic Calibrator - Class 1

Specifications

Type Approval Sound Level Frequency Distortion Reference conditions Microphone size

Standards

IEC 60942:2003 Class 1 ANSI S1.40:2006 PTB-1.61-4028829 LNE-24906 CEM 140786001 94.0 dB ± 0.2 dB 1 kHz ± 1% < 2% 23°C, 101.3 kPa, 65% RH ½" (to IEC 1094-4) Calibration adapter Battery type Dimensions Weight Controls

CE classification QD7 for use with 1/4" microphone capsules 1 x 9v (PP3, 6LR61, 6F22) 121 x Ø47 mm 220 g with battery Push button start, Automatic switch off with green LED indication. User override of automatic switch off EN 61000-6-3:2007+A1:2011

EN 61000-6-1:2007

Head Office

NoiseMeters Inc 3233 Coolidge Hwy Berkley MI 48072 USA

Telephone **888 206 4377** Fax **888 584 2230**

Email: info@noisemeters.ca Support: support@noisemeters.ca

Web Sites

Main site: https://www.noisemeters.ca

Product shortcut: https://www.noisemeters.ca/p/cr515/

Tech Support: https://support.noisemeters.com