

## Class 2 Dual Level Sound Calibrator



### Features

- IEC 60942:2003 Class 2
- ANSI S1.40:2006
- Dual level 94 and 114 dB
- Frequency 1 kHz
- Fits ½" microphones
- Adapter available for ¼" microphones

### Applications

- Calibration check of Class 2 sound level meter
- Calibration check of noise dosimeters
- One calibrator for multiple meters
- Field calibration checks

### Overview

The CR516 Acoustic Calibrator meets ANSI S1.40:2006 and IEC 60942:2003 to Class 2. It is designed for use with the Class 2 sound level meters and noise dosimeters that NoiseMeters offers.

Hand held sound level meters generally expect a calibration level of 94 dB at a frequency of 1 kHz. Noise dosimeters, which mount on a worker's shoulder to monitor daily noise exposure levels, often expect a calibration level of 114 dB at 1 kHz. Rather than having two calibrators the CR516 can be switched on at either 94 dB or 114 dB for use with either noise measurement device.

### Using It

When the Calibrator is switched on it emits a 1 kHz tone at either 94 dB or 114 dB. The calibrator should be pushed carefully (firmly, but slowly) on to the microphone capsule of the sound level meter or noise dosimeter.

The meter should now be adjusted accordingly. Older sound level meters will have to be adjusted manually to the correct reading. Most modern meters (and all those supplied by NoiseMeters) adjust themselves automatically.

## Class 2 Dual Level Sound Calibrator

### Specifications

Standards	IEC 60942:2017 Class 2 ANSI S1.40:2006	Calibration adapter	QD7 for use with 1/4" microphone capsules
Sound Level	94.0 dB $\pm$ 0.4 dB 114.0 dB $\pm$ 0.4 dB	Battery type	1 x 9v (PP3, 6LR61, 6F22)
Frequency	1 kHz $\pm$ 1%	Dimensions	121 x $\varnothing$ 47 mm
Distortion	< 2%	Weight	220 g with battery
Reference conditions	23°C, 101.3 kPa, 65% RH	Controls	Push button start at 94dB, push again for 114dB LED power indicator. Manual or auto switch off
Microphone size	1/2" (to IEC 1094-4)	CE classification	EN 61000-6-3:2007+A1:2011  EN 61000-6-1:2007

---

#### Head Office

NoiseMeters Inc  
3233 Coolidge Hwy  
Berkley  
MI 48072  
USA

Telephone **888 206 4377**  
Fax **888 584 2230**

Email: **info@noisemeters.ca**  
Support: **support@noisemeters.ca**

#### Web Sites

Main site:  
<https://www.noisemeters.ca>

Product shortcut:  
<https://www.noisemeters.ca/p/cr516/>

Tech Support:  
<https://support.noisemeters.com>