Phone: 888 206 4377

Email: info@noisemeters.ca

LiveNoise LN2-EAR Noise Monitor



Features

- Wall Mounted Noise Display
- Monitors, Analyses and Stores Sound Levels
- Network Connection (WiFi or wired Ethernet)
- Lights up when noise levels are too high
- IEC 61672 Class 2, ANSI S1.4 Type 2
- No contract or annual fees

Applications

- Office Noise
- Hospital Noise
- Call Centres
- Libraries

Overview

The noise warning sign and interface module can be mounted on a wall or other suitable surface. An optional adjustable VESA mount can be used for more secure or corner mounting if needed. It measures the sound levels in line with the noise measurement standards, stores the results, and sends them or to our cloud server.

Live Noise and Reporting

You can view the live sound level at each noise monitor or you can view long-term reports over daily, weekly, monthly or custom periods. This is all done from your web browser after logging in to your LiveNoise account.



NoiseMeters

LiveNoise LN2-EAR Noise Monitor

Specifications

Technical Specifications

Dimensions

Acoustic

IEC 61672-2:2002 Class 2

Standards

ANSI S1.4 Type 2

Frequency

20 Hz to 20 kHz

Range

Measuring 30 to 120 dB

Range

 $\begin{array}{ll} \mbox{Deviation} & \pm \mbox{ 0.5 dB} \\ \mbox{Frequency} & \mbox{"A" and "C"} \end{array}$

Weighting

Noise Leq, Fast and Slow sound

Measurements Level

Additional

0-10 V or 4-20 mA

Outputs USB Port

For USB memory stick

configuration

Ethernet Port RJ45 socket

Internal Memory 16 GB for up to 3 years storage

Dimensions

Noise Warning 265 x 205 x 46 mm, 10.4" x 8"

Sign x 1.8"

LiveNoise 70 x 88 x 29 mm, 2.8" x 3.5" x

Terminal 1.2"

Power 5 VDC, max 12W (power

adapter included)

Head Office

NoiseMeters Inc 3233 Coolidge Hwy

Berkley MI 48072 USA

Telephone **888 206 4377** Fax **888 584 2230**

Email: info@noisemeters.ca Support: support@noisemeters.ca

Web Sites

Main site:

https://www.noisemeters.ca

Product shortcut:

https://www.noisemeters.ca/product/livenoise/Int-ear/

Tech Support:

https://support.noisemeters.com